



Model 765

Fast Rise Time Pulse Generator

User Manual v1.0



Summary

- 1. MODEL 765 PULSE GENERATOR USER MANUAL COVER..... 1**
- 2. GENERAL SAFETY SUMMARY..... 5**
 - To AVOID FIRE OR PERSONAL INJURY..... 5
 - Use Proper Power Cord..... 5*
 - Ground the Product..... 5*
 - Observe All Terminal Ratings..... 5*
 - Power Disconnect..... 5*
 - Do Not Operate Without Covers..... 5*
 - Do Not Operate With Suspected Failures..... 5*
 - Avoid Exposed Circuitry..... 5*
 - Do Not Operate in Wet/Damp Conditions..... 5*
 - Do Not Operate in an Explosive Atmosphere..... 5*
 - Keep Product Surfaces Clean and Dry..... 5*
 - Provide Proper Ventilation..... 5*
- 3. SAFETY REQUIREMENTS..... 6**
 - SAFETY SYMBOLS..... 6
 - OPERATING ENVIRONMENT..... 7
 - AC POWER SOURCE..... 8
 - POWER CONSUMPTION..... 8
 - CALIBRATION..... 8
 - CLEANING..... 8
 - ABNORMAL CONDITIONS..... 8
- 4. ENVIRONMENTAL CONSIDERATIONS..... 9**
 - PRODUCT END-OF-LIFE HANDLING..... 9
 - EQUIPMENT RECYCLING..... 9
- 5. OPERATING REQUIREMENTS..... 10**
 - POWER SUPPLY..... 10
 - MECHANICAL CHARACTERISTICS..... 10
 - ENVIRONMENTAL CHARACTERISTICS..... 10
- 6. PREFACE..... 11**
- 7. PACKAGE CONTENTS..... 11**
 - 2-4 CHANNELS..... 12
 - TRIGGER, VIEW, GENERATE AND SYNC..... 12
 - TOUCH SCREEN DISPLAY AND SOFT KEYBOARD..... 12
 - Model 765 TOUCH USER INTERFACE..... 12
 - RECOMMENDED ACCESSORIES..... 13
 - POWER THE INSTRUMENT ON AND OFF..... 13
 - PROTECT YOUR INSTRUMENT FROM MISUSE..... 13
 - OBTAINING THE LATEST VERSION RELEASES..... 15
 - INSTALL PULSE GENERATOR MODEL 765 APPLICATION..... 16

8. REMOTE CONTROL	18
PREREQUISITE.....	18
AT INSTRUMENT COMMUNICATOR.....	23
9. INSTRUMENT OVERVIEW	25
FRONT PANEL.....	25
REAR PANEL.....	26
10. GETTING STARTED	26
INSTRUMENT CONTROL.....	26
<i>Front Panel Buttons</i>	27
<i>Front Panel Numeric Keypad</i>	30
11. OUTPUT AND PULSE DEFINITION	32
OUTPUT CHANNEL PARAMETERS	33
<i>Vertical Parameters</i>	33
<i>Period / Frequency</i>	34
PULSE PARAMETERS.....	35
<i>Width / Duty Cycle</i>	35
<i>Delay / Phase</i>	35
PARAMETER CONFLICTS	37
PARAMETER LIMITS.....	37
MULTIPLE PULSES OPERATION	37
<i>Hint: how to generate a clock</i>	41
12. TRIGGER CONTROLS	43
TRIGGER OUTPUT.....	43
TRIGGER INPUT.....	43
<i>Trigger Modes</i>	44
<i>Multiple Pulse Interactions</i>	52
13. QUICK START	54
SINGLE PULSE	54
DOUBLE PULSE	55
14. PULSE GENERATOR SOFTWARE	58
USER INTERFACE DESCRIPTION	58
<i>Parameters Area</i>	60
<i>Graph Area</i>	62
<i>Command Bar Area</i>	63
<i>Save / Load Setting</i>	66
<i>Trigger Setup</i>	67
<i>Output Settings</i>	69
REMOTE / LOCALE MODE.....	71
<i>Self Calibration and Diagnostic</i>	72
<i>Self Calibration</i>	72
<i>Self Diagnostic</i>	73
<i>Quick tips</i>	74

Section 2 - General Safety Summary

Review the following safety precautions to avoid injury and prevent damage to this product or any products connected to it. To avoid potential hazards, use this product only as specified.

Only qualified personnel should perform service procedures.

To Avoid Fire or Personal Injury:

Use Proper Power Cord

- ✓ Use only the power cord specified for this product and certified for the country of use.

Ground the Product

- ✓ This product is grounded through the grounding conductor of the power cord. To avoid electric shock, the grounding conductor must be connected to earth ground. Before making connections to the input or output terminals of the product, ensure that the product is properly grounded.

Observe All Terminal Ratings

- ✓ To avoid fire or shock hazard, observe all ratings and markings on the product. Consult the product manual for further ratings information before making connections to the product.

Power Disconnect

- ✓ The power cord provides Mains disconnect.

Do Not Operate Without Covers

- ✓ Do not operate this product with covers or panels removed.

Do Not Operate With Suspected Failures

- ✓ If you suspect that there is damage to this product, have it inspected by qualified service personnel.

Avoid Exposed Circuitry

- ✓ Do not touch exposed connections and components when power is present.

Provide Proper Ventilation

- ✓ Refer to the manual's installation instructions for details on installing the product so it has proper ventilation.

Maintain Controlled Operating Environments

- ✓ Do not operate in Wet/Damp Conditions.
- ✓ Do not operate in an explosive atmosphere.
- ✓ Keep product surfaces clean and dry.

Please contact Berkeley Nucleonics for the full User Manual

Berkeley Nucleonics Corporation
info@berkeleynucleonics.com | www.berkeleynucleonics.com
2955 Kerner Blvd, San Rafael, CA 94901 | 800-234-7858